

How to change the limit of AL9010

Step1. Push the three holes with change unit pin. (This pin is same as AL2500 calibration pin)



Step2. While you are pushing the unit pin, turn on the power and push the power button and you can see the following display on windows.



If you push the button continuously, we can see the message from LO1 to LO10.
LO1 means 0.01%BAC and LO2 means 0.02%BAC.

- ✓ %BAC : 0.01~0.10 (Display : L.01~L.10)
- ✓ ‰ : 0.10~1.00 (Display : L0.10~L1.00)
- ✓ mg/l : 0.05~0.50 (Display : L.05~L.50)

When your target limit is displayed, you have to release the button and then your target limit will set automatically.